

DTC	P1121/19	Accelerator Pedal Position Sensor Range/Performance Problem
------------	-----------------	--

CIRCUIT DESCRIPTION

Refer to DTC P1120/19 on page DI-101.

DTC No.	DTC Detecting Condition	Trouble Area
P1121/19	Condition (a) continue for 2.0 seconds: (a) Difference between VPA and VPA2 is out of threshold	<ul style="list-style-type: none"> • Accelerator pedal position sensor • Engine ECU

WIRING DIAGRAM

Refer to DTC P1120/19 on page DI-101.

INSPECTION PROCEDURE

HINT:

Read freeze frame data using hand-held tester. Because freeze frame records the engine conditions when the malfunction is detected, when troubleshooting it is useful for determining whether the vehicle was running or stopped, the engine warmed up or not, the air-fuel ratio lean or rich, etc. at the time of the malfunction.

Replace accelerator pedal assembly.