


DTC	P0710/38	Transmission Fluid Temperature Sensor Malfunction (ATF Temperature Sensor)
------------	-----------------	---

CIRCUIT DESCRIPTION

The ATF temperature sensor converts fluid temperature into a resistance value which is input into the Engine & ECT ECU.

DTC No.	DTC Detecting Condition	Trouble Area
P0710/38	Either 1. or 2. is detected for 0.5 sec. or more (2-trip detection logic). 1. Temperature sensor resistance is less than 79 Ω 2. After the engine has been operating for 15 minutes or more, the resistance at the temp. sensor is more than 156 k Ω	<ul style="list-style-type: none"> • Open or short in ATF temperature sensor • ATF temperature sensor • Engine & ECT ECU


WIRING DIAGRAM



Q08641

INSPECTION PROCEDURE

1 Check ATF temperature sensor.

**PREPARATION:**

- (a) Disconnect the solenoid wire connector.
- (b) Remove the oil pan.
- (c) Disconnect all solenoid valve connectors.
- (d) Remove transmission wire harness.

CHECK:

Measure resistance between terminals 1 and 7 of solenoid connector at 25°C (77°F) and 110°C (230°F).

OK:**Resistance (Approx.):**

25°C (77°F): 3.5 kΩ

110°C (230°F): 231 - 263 Ω

NG

Replace the ATF temperature sensor (transmission wire).

OK

2 Check harness and connector between ATF temperature sensor and Engine & ECT ECU (See page N-35).

NG

Repair or replace the harness or connector.

OK

Check and replace the Engine & ECT ECU (See page N-35).