


<b>DTC</b>	<b>C1231 / 31, C1335 / 35</b>	<b>Steering Angle Sensor Circuit</b>
------------	-------------------------------	--------------------------------------

**CIRCUIT DESCRIPTION**

DTC No.	DTC Detecting Condition	Trouble Area
C1231 / 31	When ECU IG1 terminal voltage is 9.5 V or more, ECU does not receive data from the steering angle sensor for 1 sec. or more.	
C1335 / 35	Detection of either condition 1. or 2.: 1. When the ECU IG1 terminal voltage is 9.5 V or more, data transmission from the steering angle sensor is impossible for 1 sec. or more. 2. Immediately after the terminal BAT is connected and when IG1 terminal voltage is 9.5 V or more, open circuit of terminal TRIG continues for 15 sec. or more.	<ul style="list-style-type: none"> <li>• Steering angle sensor</li> <li>• Steering angle sensor circuit</li> <li>• +BI circuit</li> </ul>

**WIRING DIAGRAM**



**INSPECTION PROCEDURE****HINT:**

Start the inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

<b>1</b>	<b>Check output value of the steering angle sensor.</b>
----------	---

**PREPARATION:**

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and turn the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

**CHECK:**

Check that the steering wheel turning angle value of the steering angle sensor observed in the hand-held tester is changing as the steering wheel is turned.


**OK:**

**Steering wheel turning angle value must be changing.**

<b>OK</b>	<b>Go to step 4.</b>
-----------	----------------------

<b>NG</b>
-----------

<b>2</b>	<b>Check voltage between terminals +BI and GND of skid control ECU.</b>
----------	---

**PREPARATION:**

- (a) Remove the skid control ECU with the connector still connected.
- (b) Turn the ignition switch ON.
- (c) Measure voltage between terminal +BI (S11 - 23) and GND (S14 - 15, 22, S11 - 3, 5) of skid control ECU.


**OK:**

**Voltage: 10 - 14 V**

<b>NG</b>	<b>Check and replace harness and connector.</b>
-----------	---

<b>OK</b>
-----------

**3 Check input voltage of the steering angle sensor.**



**PREPARATION:**

- (a) Remove the steering wheel and column power cover (See page RS-15).
- (b) Disconnect the steering angle sensor connector.

**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals 1 and 2, 2 and 3 of the steering angle sensor harness side connector.


**OK:**

**Voltage: 10 – 14 V**

**NG** Check and replace harness and connector.

**OK**

**4 Check steering angle sensor.**




**PREPARATION:**

- (a) Apply battery voltage between terminals 1 and 2, 2 and 3 of the steering angle sensor.
- (b) Connect the oscilloscope to the terminals 9 and 10 of the steering angle sensor.

**CHECK:**

Turn the steering wheel slowly and check the signal waveform.

**OK:**



**HINT:**

The above signal wave form does not repeat ON and OFF regularly and this ON-OFF interval changes case by case according to the data.

**NG**

**Replace steering angle sensor.**

**OK**

**Check and replace skid control ECU.**