


<b>DTC</b>	<b>C1241 / 41</b>	<b>IG Power Source Circuit</b>
------------	-------------------	--------------------------------

**CIRCUIT DESCRIPTION**

DTC No.	DTC Detecting Condition	Trouble Area
C1241 / 41	Detection of either condition 1. or 2.: 1. When the vehicle speed is 3 km/h (1.9 mph) or more, ECU IG1 terminal voltage is 9.5 V or less for 10 sec. or more. 2. While SOL relay is ON, ECU IG1 terminal voltage becomes 9.5 V or less and the condition that the contact point of the SOL relay is OFF continues for 0.2 sec. or more.	<ul style="list-style-type: none"> <li>• Battery</li> <li>• Charging system</li> <li>• Power source circuit</li> </ul>

**WIRING DIAGRAM**



**INSPECTION PROCEDURE**

<b>1</b>	<b>Check battery voltage.</b>
----------	-------------------------------


**OK:**

Voltage: 10 - 14 V

<b>NG</b>	<b>Check and repair the charging system.</b>
-----------	----------------------------------------------

<b>OK</b>
-----------

<b>2</b>	<b>Check ABS-IG fuse.</b>
----------	---------------------------

**PREPARATION:**

Remove the ABS-IG fuse from the driver side J/B.

**CHECK:**

Check continuity of ABS-IG fuse.

**OK:****Continuity**

<b>NG</b>	<b>Check for short circuit in all the harnesses and components connected to ABS-IG fuse (See attached wiring diagram).</b>
-----------	----------------------------------------------------------------------------------------------------------------------------

<b>OK</b>
-----------

**3 Check voltage of the ECU IG power source.**

**In case of using the hand-held tester:**

**PREPARATION:**


- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and turn the hand-held tester main switch ON.
- (c) Select the DATALIST mode on the hand-held tester.

**CHECK:**

Check the voltage condition output from the ECU observed in the hand-held tester.

**OK:**

**"Normal" is displayed.**



**In case of not using the hand-held tester:**

**PREPARATION:**

Remove the skid control ECU with the connectors still connected to it.

**CHECK:**

- (a) Turn the ignition switch ON.
- (b) Measure voltage between the terminals IG1 (S12 – 6) and GND (S14 – 15, 22, S11 – 3, 5) of the skid control ECU.

**OK:**


**Voltage: 10 – 14 V**

**OK**

**Check and replace skid control ECU.**

**NG**

4 Check continuity between terminal GND of skid control ECU connector and body ground.

**PREPARATION:**

Disconnect the 2 connectors (S14, S11) from the skid control ECU.

**CHECK:**

Measure resistance between the terminal GND (S14 - 15, 22, S11 - 3, 5) of the skid control ECU and body ground.

**OK:**

Resistance: 1 Ω or less

NG

Repair or replace harness or connector.

OK

Check for open circuit in harness and connector between skid control ECU and battery (See page IN-35).