

PROBLEM SYMPTOMS TABLE

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspected Area	See page
<ul style="list-style-type: none"> • With the ignition switch in ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed. 	<ul style="list-style-type: none"> • SRS warning light circuit 	DI-707
<ul style="list-style-type: none"> • SRS warning light is always lit up even when ignition switch is in the LOCK position. 		
<ul style="list-style-type: none"> • With the ignition switch in ON position, the SRS warning light does not light up. 		
<ul style="list-style-type: none"> • DTC is not displayed. 	<ul style="list-style-type: none"> • Tc terminal circuit 	DI-711
<ul style="list-style-type: none"> • SRS warning light is always lit up at the time of DTC check procedure. 		
<ul style="list-style-type: none"> • DTC is displayed without Tc and CG terminal connection. 		