

<b>DTC</b>	<b>B1150/23</b>	<b>Occupant Detection Sensor Malfunction</b>
------------	-----------------	--

## CIRCUIT DESCRIPTION


The occupant detection sensor circuit consists of the airbag sensor assembly and occupant detection sensor.

For details of the function of each component, see OPERATION on page RS-3.

DTC B1150/23 is recorded when a malfunction is detected in the occupant detection sensor circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1150/23	• Occupant detection sensor malfunction	<ul style="list-style-type: none"> <li>• Occupant detection sensor</li> <li>• Airbag sensor assembly</li> <li>• Wire harness</li> </ul>


## WIRING DIAGRAM



## INSPECTION PROCEDURE

1 Prepare for inspection (See step 1 on page DI-484).

2 Check wire harness (to ground).

**CHECK:**

For the connector (on the airbag sensor assembly side) between the occupant detection sensor and the airbag sensor assembly, measure the resistance between body ground and each of FSR+ and FSR-.

**OK:**


**Resistance: 1 MΩ or Higher**

NG

Repair or replace wire harness.

OK

3 Check wire harness (to B+).

**PREPARATION:**

Deactivate the LEXUS Link system (See page DI-484).

**CHECK:**

- Turn the ignition switch to ON.
- For the connector (on the airbag sensor assembly side) between the occupant detection sensor and the airbag sensor assembly, measure the voltage between body ground and each of FSR+ and FSR-.

**OK:**


**Voltage: Below 1 V**

NG

Repair or replace wire harness.

OK

#### 4 Check occupant detection sensor.



#### **CHECK:**

Without passenger on a passenger seat:

For the connector of the occupant detection sensor, connect the positive (+) lead from the ohmmeter to terminal FSR+ and the negative (-) lead to terminal FSR-, measure the resistance between FSR+ and FSR-.

#### **OK:**

**Resistance: 50 k $\Omega$  or Higher**

#### **CHECK:**

With passenger on a passenger seat:

For the connector of the occupant detection sensor, connect the positive (+) lead from the ohmmeter to terminal FSR+ and the negative (-) lead to terminal FSR-, measure the resistance between FSR+ and FSR-.

#### **OK:**


**Resistance: Below 50 k $\Omega$**

**NG**

**Replace seat cushion cover.**

**OK**

## 5 Check airbag sensor assembly.



### PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the occupant detection sensor connector and airbag sensor assembly connector.
- Connect the negative (-) terminal cable to the battery, and wait at least for 2 seconds.

### CHECK:

- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See step 5 on page DI-484).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page DI-484).

### OK:

**DTC B1150/23 is not output.**

### HINT:

Codes other than code B1150/23 may be output at this time, but they are not relevant to this check.

**NG**

**Replace airbag sensor assembly.**

**OK**

**From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check.**