


## Power source circuit

### CIRCUIT DESCRIPTION

This circuit provides power to operate the Transponder Key ECU.

### WIRING DIAGRAM



**INSPECTION PROCEDURE**

|          |                                   |
|----------|-----------------------------------|
| <b>1</b> | <b>Check MPX-B1 and IG2 fuse.</b> |
|----------|-----------------------------------|

**CHECK:**

Check continuity of MPX-B1 and IG2.

**OK:**

**Continuity**



**Replace the failure fuse.**



|          |   |
|----------|---|
| <b>2</b> | <b>Check voltage between terminals IG, CPUB and GND of transponder key ECU connector.</b> |
|----------|---|

**PREPARATION:**

Turn the ignition switch ON.

**CHECK:**

Measure voltage between terminals IG and GND.

**OK:**

**Voltage: 10 – 14 V**

**PREPARATION:**

- (a) Turn the ignition switch OFF.
- (b) Disconnect the transponder key ECU connector.

**CHECK:**


Measure voltage between terminals CPUB and GND.

**OK:**

**Voltage: 10 – 14 V**



**Proceed to next circuit inspection shown in problem[symptoms]table[(See[page]DI-907).**



3 Check wire harness and connector between transponder key ECU and body ground (see page IN-35).

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown on problem/symptom table (See page DI-907).