


## Power Source Circuit

### CIRCUIT DESCRIPTION

This circuit provides power to operate the Driver side J/B ECU.

# WIRING DIAGRAM



## INSPECTION PROCEDURE


1	Check MPX-B3, MPX-IG, B/ANC, HAZ and PANEL fuse.
---	--

**CHECK:**

Check continuity of MPX-B3 and MPX-IG, B/ANC, HAZ and PANEL fuse.

**OK:**

Continuity



2	Check voltage between terminal MPXB, MPX-IG, B/ANC, HAZ and PANEL1 and GND, GND2 of driver side junction block.
---	---

**PREPARATION:**

Turn the ignition switch ON.

**CHECK:**

Measure voltage between terminals MPX-IG and GND of driver side J/B.

**OK:**

Voltage: 10 – 14 V

**PREPARATION:**

(a) Turn the ignition switch OFF.



(b) Disconnect the driver side junction block.

**CHECK:**

Measure voltage between terminals MPXB, B/ANC, HAZ, PANEL1 and GND2 of driver side J/B.

**OK:**

Voltage: 10 – 14 V



3 Check wire harness and connector between driver side J/B ECU and body ground (See page IN-35).

NG

Repair or replace wire harness or connector.

OK

Proceed to next circuit inspection shown on problem/symptom table (See page DI-1012).