


Power source circuit

CIRCUIT DESCRIPTION

This circuit supplies power to operate the rear left door ECU.

WIRING DIAGRAM



N

I19818

INSPECTION PROCEDURE

1	Check MPX-B1, MPX-IG and RL-DOOR LH fuse.
---	---

CHECK:

Check continuity of MPX-B1, MPX-IG and RL-DOOR LH fuse.

OK:

Continuity

NG

Replace defective fuse.

OK

2	Check voltage between terminals BDR, CPUB, SIG and GND of rear door LH ECU connector.
---	---

PREPARATION:

Turn the ignition switch ON.

CHECK:

Measure the voltage between terminals SIG and GND.

OK:

Voltage: 10 – 14V

PREPARATION:

- (a) Turn the ignition switch OFF.
- (b) Disconnect the rear door LH ECU connector.

CHECK:

Measure the voltage between terminals BDR, CPUB and GND.

OK:

Voltage: 10 – 14V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-1395).

NG

3 Check wireharness and connector between ECU and body ground (See page IN-35).

NG

Repair or replace wireharness or connector

OK

Proceed to next circuit inspection shown on problem/symptom table (See page DI-1395).