

DIAGNOSTIC TROUBLE CODE CHART

Terms	Meaning
Physical address	Three-digit code (shown in hexadecimal) which is given to each component comprising the AVC-LAN. Corresponding to the function, individual symbols are specified.
Logical address	Two-digit code (shown in hexadecimal) which is given to each function comprising the inner system of the AVC-LAN.

1. GATEWAY ECU (Physical address: 1C4)

HINT:

*1: When 210 sec. has passed after pulling out the power supply connector of the master component with the ignition switch in ACC or ON, this code is stored.

Logical address: 01 (Communication control)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
D4 *1	Regular Communication Error	Component in which this code is recorded has been disconnected after engine start. Or, when this code was recorded, multi-display was disconnected.	<ul style="list-style-type: none"> • Check harness for power supply system of multi-display assembly. • Check harness for communication system of multi-display assembly. • Check harness for power supply system of gateway ECU. • Check harness for communication system of gateway ECU.

2. RADIO AND PLAYER (Physical address: 190)

HINT:

- *1: Even if no failure is detected, this code may be stored depending on the battery condition or voltage for starting the engine.
- *2: This code is stored when 180 sec. has passed after the power supply connector is pulled out after engine start.
- *3: This code may be stored when the engine key is turned again 1 min. after engine start.
- *4: This code may be stored when the engine key is turned again after engine start.
- *5: When 210 sec. has passed after pulling out the power supply connector of the master component with the ignition switch in ACC or ON, this code is stored.

(a) Logical address: 01 (Communication control)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
D6 *1	Absence of Master	Component in which this code is recorded has been disconnected from system with ignition in ACC or ON. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> • Check harness for power supply system of multi-display. • Check harness for communication system of multi-display. • Check harness for power supply system of radio and player. • Check harness for communication system of radio and player.
D8 *2	No Response to Connection Check	Component shown by auxiliary code is or had been disconnected from system after engine is start.	<ul style="list-style-type: none"> • Check harness for power supply system of component shown by auxiliary code. • Check harness for communication system of component shown by auxiliary code.
D9 *1	Last Mode Error	Component operated (sounds and/or images were provided) before engine stop is or has been disconnected with ignition switch in ACC or ON.	<ul style="list-style-type: none"> • Check harness for power supply system of component shown by auxiliary code. • Check harness for communication system of component shown by auxiliary code.

DA	No Response to ON/OFF Instruction	No response is identified when changing mode (audio and visual mode change). Detected when sound and picture does not change by button operation.	<ul style="list-style-type: none"> • Check harness for power supply system of component shown by auxiliary code. • Check harness for communication system of component shown by auxiliary code. • If error occurs again, replace component shown by auxiliary code.
DB *1	Mode Status Error	Dual alarm is detected.	<ul style="list-style-type: none"> • Check harness for power supply of component shown by auxiliary code. • Check harness for communication system of component shown by auxiliary code.
DC *3	Transmission Error	Transmission to component shown by auxiliary code has been failed. (Detecting this DTC does not necessarily mean actual failure.)	If same auxiliary code is recorded in other component, check harness for power supply and communication system of all components shown by code.
DD *4	Master Reset (Momentary Interruption)	After engine was started, multi-display assembly was disconnected from system.	<ul style="list-style-type: none"> • Check harness for power supply system of multi-display. • Check harness for communication system of multi-display. • Check harness for power supply system of radio and player. • Check harness for communication system of radio and player. • If this error occurs frequently, replace multi-display assembly.
DE *4	Slave Reset (Momentary Interruption)	After engine was started, slave component was disconnected from system.	<ul style="list-style-type: none"> • Check harness for power supply of component shown by auxiliary code. • Check harness for communication system of component shown by auxiliary code.
DF *5	Master Error	Due to defective condition of component with a display, master function is switched to audio equipment. Error occurs in communication between sub-master (audio) and master component.	<ul style="list-style-type: none"> • Check harness for power supply of multi-display assembly. • Check harness for communication system of multi-display assembly. • Check harness for communication system between multi-display assembly and sub-master component.
E0 *1	Registration Completion Instruction Error	"Registration Completion Instruction" command from master cannot be received.	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.
E1 *1	Audio processor ON error	While source equipment is operating, AMP output is stopped.	<ul style="list-style-type: none"> • Check harness for power supply of multi-display assembly. • Check harness for communication system of multi-display assembly.
E2	ON/OFF Instruction Parameter Error	Error occurs in ON/OFF controlling command from multi-display assembly.	Replace multi-display assembly.
E3 *1	Registration Request Transmission	Registration Request command is output from slave component. Receiving Connection Check Instruction, Registration Request command is output from sub-master component.	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.
E4 *1	Multiple Frame Abort	Multiple frame transmission is aborted.	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.

(b) Logical address: 61 (Cassette switch)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
40	Mechanical error of Media	Malfunction due to mechanical failure is identified. Or cassette tape is cut or entangled.	<ul style="list-style-type: none"> Inspect cassette tape. Replace radio and player.

(c) Logical address: 63 (In-dash CD changer)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
42	No Disc Readout	Disc cannot be read.	Inspect CD.
44	CD Error	Error is detected in CD player.	Replace radio and player.
45	EJECT Error	Disc cannot be ejected.	Replace radio and player.
47	CD High Temp.	High temperature is detected in CD changer.	Replace radio and player.
48	CD Excess Current	Excess current is applied to CD changer.	Replace radio and player.

3. STEREO COMPONENT AMPLIFIER (Physical address: 440)

HINT:

- *1: Even if no failure is detected, this code may be stored depending on the battery condition or voltage for starting an engine.
- *2: This code be stored when the engine key is turned again 1 min. after engine start.
- *3: This code may be stored when the engine key is turned again after engine start.
- *4: When 210 sec. has passed after pulling out the power supply connector of the master component with the ignition switch in ACC or ON, this code is stored.

Logical address: 01 (Communication control)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
D6 *1	Absence of Master	Component in which this code is recorded has been disconnected from system with ignition in ACC or ON. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> Check harness for power supply of radio and player. Check harness for communication system of radio and player. Check harness for power supply of stereo component amplifier. Check harness for communication system of stereo component amplifier.
D7	Communication Check Error	Component in which this code is recorded is or was disconnected from system after engine start. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> Check harness for power supply of radio and player. Check harness for communication system of radio and player. Check harness for power supply of stereo component amplifier. Check harness for communication system of stereo component amplifier.
DC *2	Transmission Error	Transmission to component shown by auxiliary code has been failed. (Detecting this DTC does not necessarily mean actual failure.)	If same auxiliary code is recorded in other component, check harness for power supply and communication system of all components shown by code.
DD *3	Master Reset (Momentary Interruption)	After engine was started, multi-display assembly was disconnected from system.	<ul style="list-style-type: none"> Check harness for power supply of radio and player. Check harness for communication system of radio and player. Check harness for power supply of stereo component amplifier. Check harness for communication system of stereo component amplifier. If this error occurs frequently, replace multi-display assembly.

DF *4	Master Error	Due to defective condition of component with a display, master function is switched to audio equipment. Error occurs in communication between sub-master (audio) and master component.	<ul style="list-style-type: none"> • Check harness for power supply of multi-display assembly. • Check harness for communication system of multi-display assembly. • Check harness for communication system between multi-display assembly and sub-master component.
E0 *1	Registration Completion Instruction Error	"Registration Completion Instruction" command from master cannot be received.	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.
E1 *1	Audio processor ON error	While source equipment is operating, AMP output is stopped.	<ul style="list-style-type: none"> • Check harness for power supply of multi-display assembly. • Check harness for communication system of multi-display assembly.
E2	ON/OFF Instruction Parameter Error	Error occurs in ON/OFF controlling command from multi-display assembly.	Replace multi-display assembly.
E3 *1	Registration Request Transmission	<ul style="list-style-type: none"> • Registration Request command is output from slave component. • Registration Connection Check Instruction, Registration Request command is output from sub-master component. 	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.

4. STEREO COMPONENT TURNER (Physical address: 1FO)

HINT:

- *1: Even if no failure is detected, this code may be stored depending on the battery condition or voltage for starting an engine.
- *2: This code may be stored when the engine key is turned again 1 min. after engine start.
- *3: This code may be stored when the engine key is turned again after engine start.
- *4: When 210 sec. has passed after pulling out the power supply connector of the master component with the ignition switch in ACC or ON, this code is stored.

Logical address: 01 (Communication control)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
D6 *1	Absence of Master	Component in which this code is recorded has been disconnected from system with ignition in ACC or ON. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> • Check harness for power supply of stereo component tuner. • Check harness for communication system of stereo component tuner. • Check harness for power supply system of radio and player. • Check harness for communication system radio and player.
D7	Communication Check Error	Component in which this code is recorded is or was disconnected from system after engine start. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> • Check harness for power supply of stereo component tuner. • Check harness for communication system of stereo component tuner. • Check harness for power supply system of radio and player. • Check harness for communication system radio and player.
DC *2	Transmission Error	Transmission to component shown by auxiliary code has been failed. (Detecting this DTC does not necessarily mean actual failure.)	If same auxiliary code is recorded in other component, check harness for power supply and communication system of all components shown by code.

DIAGNOSTICS - AUDIO SYSTEM

DD *3	Master Reset (Momentary Interruption)	After engine start multi-display assembly was disconnected from system.	<ul style="list-style-type: none"> • Check harness for power supply system of stereo component tuner. • Check harness for communication system of stereo component tuner. • Check harness for power supply system of radio and player. • Check harness for communication system radio and player. • If this error occurs frequently, replace multi-display assembly.
DF *4	Master Error	Due to defective condition of component with a display, master function is switched to audio equipment. Error occurs in communication between sub-master (audio) and master component.	<ul style="list-style-type: none"> • Check harness for power supply of multi-display assembly. • Check harness for communication system of multi-display assembly. • Check harness for communication system between multi-display assembly and radio and player.
E0 *1	Registration Completion Instruction Error	"Registration Completion Instruction" command from master cannot be received.	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.
E2	ON/OFF Instruction Parameter Error	Error occurs in ON/OFF controlling command from radio and player.	Replace radio and player.
E3 *1	Registration Request Transmission	<ul style="list-style-type: none"> • Registration Request command is output from slave component. • Receiving Connection Check Instruction, Registration Request command is output from sub-master component. 	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.

5. AUDIO AND A/C CONTROL SWITCH (Physical address: 1C0)**HINT:**

- *1: Even if no failure is detected, this code may be stored depending on the battery condition or voltage for starting an engine.
- *2: This code may be stored when the engine key is turned again 1. min after engine start.
- *3: This code may be stored when the engine key is turned again after engine start.
- *4: When 210 sec. has passed after pulling out the power supply connector of the master component with the ignition switch in ACC or ON, this code is stored.

Logical address: 01 (Communication control)

DTC	Diagnosis item	Condition	Countermeasure and inspected parts
D6 *1	Absence of Master	Component in which this code is recorded has been disconnected from system with ignition in ACC or ON. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> • Check harness for power supply system of multi-display. • Check harness for communication system multi-display. • Check harness for power supply system of audio and rear A/C control switch. • Check harness for communication system audio and rear A/C control switch.
D7 *2	Communication Check Error	Component in which this code is recorded is or was disconnected from system after engine start. Or, when this code was recorded, multi-display assembly was disconnected.	<ul style="list-style-type: none"> • Check harness for power supply system of multi-display. • Check harness for communication system of multi-display. • Check harness for power supply system of audio and rear A/C control switch. • Check harness for communication system audio and rear A/C control switch.

DC *2	Transmission Error	Transmission to component shown by auxiliary code has been failed. (Detecting this DTC does not necessarily mean actual failure.)	If same auxiliary code is recorded in other component, check harness for power supply and communication system of all components shown by code.
DD *3	Master Reset (Momentary Interruption)	After engine start, multi-display assembly was disconnected from system.	<ul style="list-style-type: none"> • Check harness for power supply system of multi-display. • Check harness for communication system of multi-display. • Check harness for power supply system of audio and rear A/C control switch. • Check harness for communication system of audio and rear A/C control switch • If this error occurs frequently, replace multi-display assembly.
DF *4	Master Error	Due to defective condition of component with a display, master function is switched to audio equipment. Error occurs in communication between sub-master (audio) and master component.	<ul style="list-style-type: none"> • Check harness for power supply of multi-display assembly. • Check harness for communication system of multi-display assembly. • Check harness for communication system between multi-display assembly and radio and player.
E0 *1	Registration Completion Instruction Error	"Registration Completion Instruction" command from master cannot be received.	Since this DTC is provided for engineering, it may be detected when no actual failure exists.
E3 *1	Registration Request Transmission	<ul style="list-style-type: none"> • Registration Request command is output from slave component. • Receiving Connection Check Instruction, Registration Request command is output from sub-master component. 	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.
E4 *1	Multiple Frame Abort	Multiple frame transmission is aborted.	Since this DTC is provided for engineering purpose, it may be detected when no actual failure exists.