


ENGINE IMMOBILISER SYSTEM

1. General

- The engine immobiliser system has been designed to prevent the vehicle from being stolen. This system uses a transponder key ECU or steering lock ECU that stores the ID code of the authorized ignition key. If an attempt is made to start the engine using a non-authorized key, the transponder computer emits a signal to the engine ECU to prohibit fuel delivery and ignition, effectively disabling the engine.
- The transponder key ECU on the models with a smart key is enclosed in the steering lock ECU.

► System Diagram ◀




*1: without Smart Key System

*2: with Smart Key System

189BE193

2. Layout of Component



*1: without Smart Key System

*2: with Smart Key System

189BE202