

## GENERAL FEATURES

### DESCRIPTION

The new LEXUS models have the following systems:

System	Outline	Model Name
Coolant System	The engine coolant has been changed to extend the maintenance interval from TOYOTA Genuine LLC (Long Life Coolant) to TOYOTA Genuine SLLC (Super Long Life Coolant).	LS430, SC430, GS430/300, ES300, IS300/200, LX470

### COOLING SYSTEM

#### ■ ENGINE COOLANT

The differences between TOYOTA Genuine SLLC (Super Long Life Coolant) and TOYOTA Genuine LLC (Long Life Coolant) are as follows.

Type		TOYOTA Genuine SLLC	TOYOTA Genuine LLC
Maintenance Interval	First Time	100,000 miles (160,000 km)	<p><b>Europe Model:</b> Every 60,000 km (36,000 miles) or 36 months whichever come first, after that replace at every 30,000 km (18,000 miles) or 24 months whichever comes first</p> <p><b>G.C.C. Countries Model:</b> Every 40,000 km or 24 months whichever come first</p> <p><b>Australia Model:</b> <b>(Except New Zealand)</b> Every 40,000 km or 24 months whichever come first</p> <p><b>(New Zealand)</b> Every 30,000 km or 24 months whichever come first</p>
	Subsequent	Every 50,000 miles (80,000 km)	
Color		Pink	Red

- SLLC is pre-mixed (50% coolant and 50% distilled water), so no dilution is needed when adding or replacing SLLC in the vehicle.
- If LLC is mixed with SLLC, the interval for LLC should be used.
- You can also apply the new maintenance interval (every 50,000 miles/80,000 km) to vehicles initially filled with LLC (red-colored), if you use SLLC (pink-colored) for the engine coolant change.