



SUPPLEMENTAL RESTRAINT SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

D160W-10

Items inside  are titles of pages in this manual, with the page number in the bottom portion. See the pages for detailed explanations.



Step 4, 5, 7, 8, 10 : Diagnostic steps permitting the use of the hand-held tester.