

PROBLEM SYMPTOMS TABLE

Symptom	Suspect Area	See page
All function of rear power seat system does not operate. (Both left and right)	<ol style="list-style-type: none">1. Power source circuit2. Rear seat switch circuit3. Rear seat switch	DI-788 DI-790 IN-35