

STEERING LOCK SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

DISV-01

HINT:

This ECU is connected to the multiplex communication system. Therefore, be sure to check that there is no troubles in the multiplex communication system before performing the troubleshooting.

