


PARTS LOCATION

Combination Switch Assembly

- Combination Switch ECU
- Light Control Switch
- Headlight Dimmer Switch
- Wiper and Washer Switch
- Tilt and Telescopic Manual Switch



Driver Side J/B

- MPX-B3 Fuse
- MPX-IG Fuse