

**PROBLEM SYMPTOMS TABLE**

Symptom	Suspect Area	See page
Auto wiper system does not operate.	1. Rain sensor power source circuit 2. Rain sensor	<a href="#">DI-986</a> <a href="#">IN-35</a>
Auto wiper switch is set to "AUTO", it functions as "INT".	1. Rain sensor power source circuit 2. Rain sensor	<a href="#">DI-986</a> <a href="#">IN-35</a>