

## DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during DTC check, find the circuit corresponding to the code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
B1226 (DI-1396)	Power Window Switch Circuit on Rear Left Door	<ul style="list-style-type: none"> <li>• Power window switch</li> <li>• Wire harness</li> <li>• Rear left door control ECU</li> </ul>
B1237 (DI-1397)	Jam Protection Limit Switch Circuit on Rear Left Door	<ul style="list-style-type: none"> <li>• Jam protection limit switch</li> <li>• Wire harness</li> <li>• Rear left door control ECU</li> </ul>
B1238 (DI-1400)	Jam Protection Pulse Switch Circuit on Rear Left Door	<ul style="list-style-type: none"> <li>• Jam protection pulse switch</li> <li>• Wire harness</li> <li>• Rear left door control ECU</li> </ul>
B2214 (DI-1402)	Door Closer and Double Locking Motor Malfunction on Rear Left Door	<ul style="list-style-type: none"> <li>• Door closer</li> <li>• Double locking motor</li> <li>• Wire harness</li> <li>• Rear left door control ECU</li> </ul>