

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during DTC check, find the circuit corresponding to the code in the table below and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
B1225 (DI-1340)	Power Window Switch Circuit on Rear Right Door	<ul style="list-style-type: none"> • Power window switch • Wire harness • Rear door RH ECU
B1235 (DI-1341)	Jam Protection Limit Switch Circuit on Rear Right Door	<ul style="list-style-type: none"> • Jam protection limit switch • Wire harness • Rear door RH ECU
B1236 (DI-1344)	Jam Protection Pulse Switch Circuit on Rear Right Door	<ul style="list-style-type: none"> • Jam protection pulse switch • Wire harness • Rear door RH ECU
B2213 (DI-1346)	Door Closer and Double Locking Motor Malfunction on Rear Right Door	<ul style="list-style-type: none"> • Door closer • Double locking motor • Wire harness • Rear door RH ECU