

## 7. Cassette tape cannot be inserted.

### INSPECTION PROCEDURE

1 Is there a foreign object inside tape player?

Yes

Remove foreign object.

No

2 Is auto search function of radio operating normally?

NG

Radio and player is faulty.

OK

3 Check cassette tape for deformation or peeled label.

NG

Replace cassette tape.

OK

4 Is cassette tape slack?

NG

Remove slack before using.

OK

Replace radio and player.