

12. Turning Light Control switch "TAIL" does not light up radio receiver switches.

INSPECTION PROCEDURE

1 Check radio and player.

CHECK:

Check terminal ILL+.

OK:

ILL+: See "Radio and Player" of "TERMINAL OF ECU".

OK

Replace radio and player (See page IN-35).

NG

Replace and repair wire harness (See page IN-35).