

## CIRCUIT INSPECTION

### 1. Black screen (Nothing displayed)

#### INSPECTION PROCEDURE

1 Check RADIO NO. 1, P-ACC and P-IG fuse.

NG

Replace fuse.

OK

2 Check multi display.

#### **PREPARATION:**

Disconnect the multi display connector.

#### **CHECK:**

Check the voltage of terminal +B.

#### **OK:**

+B: 10 - 14 V

#### **CHECK:**

Check the voltage of terminal ACC when the ignition switch is in ACC or ON position.

#### **OK:**

ACC: 10 - 14 V

#### **CHECK:**

Check continuity at terminal GND.

#### **OK:**

GND: Continuity

NG

Replace or repair wire harness or connector  
(See [page IN-35](#)).

OK

Replace multi display (See [page IN-35](#)).