

4. No corresponding screen displayed when "AUDIO" or "A/C" switch pressed.

INSPECTION PROCEDURE

Replace multi display (See page N-35).