DI8QO–01

PARTS LOCATION




Inside Handle Illumination Rear RH
Seat Position Memory Switch
Rear Door LH ECU
Ashtray
• Ashtray Light
Power Window Switch
Door Oscillator Rear LH
Door Lock Assembly
• Door Unlock Detection Switch
• Door Lock Motor
• Door Closer Switch
• Double Locking and Closer Motor
• Door Closer Position Switch
• Cam Position Switch
Power Window Motor
• Jam Protection Limit Switch
• Jam Protection Pulse Switch
Outside Handle
● Touch Sensor
● Trigger Switch
Courtesy Light
Door Courtesy Switch
P
I19005